

# Safe-T-View Cover installation instructions

1. Carefully un-wrap your new Safe-T-View cover without the use of a box cutter to ensure not damaging the XL polycarbonate. Please contact your local recycling center for responsible disposal of the cardboard packaging.

2. Simply squeeze and size the pre-installed spring clips to the correct length and width dimensions for your previously installed areawall. Hand adjustments can be made as you lay the cover over the window well opening.



3. Attach the safety retainer-hinge lanyards via the top bolts mounting the areawall to the foundation. \*Alternatively, anchor the loop end of

the lanyard to the home foundation or directly to the areawall itself depending on your particular application. Allow for enough lanyard length so the cover will pivot up and stay propped open against the side of the house.



4. Peel back the protective film from the UV protected polycarbonate to enjoy the clearest view available from any cover available.

Now stand back and take pleasure in the fact that in just minutes, you've installed the sturdiest, most innovative, and easiest to install cover product available today. Well done!

## Safe-T-View Limited lifetime warrantee

St Paul Corrugating, ("SPC") warrants Safe-T-View Window Well Covers ("Covers") to the original purchaser for a lifetime against breakage due to defects in materials or workmanship. For a period of ten (10) years from the date of purchase for excessive yellowing or discoloring of the XL polycarbonate, provided in each case that the Covers are used for their intended purposes only, and are maintained by the purchaser in accordance with the instructions provided with each Cover. Please contact us for the complete details on this unique warrantee.

### Maintenance & Cleaning

Check cover(s) regularly to see that it has not shifted or moved from its properly installed position. Covers should be kept clean to eliminate the build up of hard water spots. Clean using only a non-abrasive cloth with biodegradable soap and water. SPC Safe-T-View Covers should be inspected and cleaned periodically. Inspection should include checking to see that the cover is still in its properly installed position and adjusted if necessary. Please inspect the cover to see if any parts are broken or missing as well. Any broken or missing parts should be repaired or replaced immediately. Hard water deposits can cause discoloration that is not covered under the warranty. Buildup of hard water deposits would suggest that the cover was not cleaned and maintained and can void any and all warranties.

Rev. 05/05/2005

© 2005 St Paul Corrugating Company. All Rights Reserved  
www.safeTviewcover.com